



GOCYCLE SERVICE NOTICE 3.0

X	HIGHLY RECOMMENDED	WITH SERVICE ACTION, NON-SAFETY CRITICAL COMPONENT FAILURE CAN OCCUR
---	--------------------	----------------------------------------------------------------------

MANDATORY
HIGHLY RECOMMENDED
RECOMMENDED

Maintaining the Gocycle Battery

Service Issue

Improper care and charging of your battery may void the battery warranty.

Corrective Action

- For best performance and long life of the battery, you should place the battery on charge immediately after any riding and leave it charging continuously 24 hours per day. This is approximately the equivalent of leaving a 40 watt light bulb on for 1 hour per day.
- The next best practice for your battery is to charge it fully at least once per week and always immediately after a ride.
- The third best practice for your battery is to charge it fully, and then unplug the controller. You can then leave the battery for up to one month before fully recharging it.
- Never leave your battery in a depleted or partially charged state.
- When in doubt, put the battery on charge and leave it on charge!

WARNING! If you hear multiple beeps from the controller every 2 to 3 minutes, your battery pack is dangerously low on voltage and needs immediate charging. This is the low voltage alarm alerting you that the battery is being damaged. ***The controller records these low voltage alarms, and recordings of excess alarm readings could void the warranty.***
